

BRACKET INSTALLATION FOR 104012 HIGH BAY FIXTURE

1. Remove wing nuts and screws from the sides of the Reflector Bracket
2. Remove the nuts from the bolts on the base of the Reflector Bracket
3. Remove the bolts from the base.
4. Place the base of the reflector bracket with the sides facing up on the outside Top of the reflector.
5. Put the bolts with washer through the holes in the reflector and base.
6. Tighten down the nuts.
7. Slide the newly attached reflector on the outside of the sides on the gear box bracket.
8. Put the bolts through the slot in the center of the gearbox bracket and through the hole in the reflector bracket.
9. Screw on the wing nuts to the bolts.
10. Pull the reflector bracket all the way down.
11. Tighten down the wing nuts.
12. The reflector should be attached to the gearbox and a distance of approximately 2 ¼ inches should be between the reflector and gearbox.