

TekCoil Red Pex-B Installation Guide



Step 1: Cutting the pipe

Cut the pipe vertically with our Plastic Pipe and Tube Cutter. Make sure to cut it quickly and precisely.



Step 3: Sleeving

Put the copper crimp ring over the pipe at the open end. Insert the fitting body into the pex pipe until the shoulder of the fitting reaches the pex pipe. Make sure the insert is completely inside the pipe and contact between fitting and pipe is clean and free of debris.



Step 2: Selecting fitting and jaw

Choose the right size fitting for the jaw of the crimping tool.



Step 4: Pressing

Open the crimping tool and put the fitting into the jaw. Press the jaw until it closes completely. While pressing make sure the crimping jaw is vertical to the pipe. The pressing contact must be free of debris.