

QUICK-START GUIDE

Rat Zapper *Ultra*

Open Battery Compartment:

The **Rat Zapper *Ultra*** battery compartment is located on the top of the unit. To open, pull the securing tap back then lift the battery compartment door. Properly install 4 "D" batteries in the battery holder and re-secure the lid to **the** battery compartment.

Important Information: The performance of your Rat Zapper *Ultra* will depend upon:

- 1) The quality of batteries;
- 2) The amount of time your Rat Zapper *Ultra* is turned on;
- 3) The number of rodents killed;
- 4) The cleanliness of the unit floor.

Rating	Battery Type	Expected Use *
BEST	Duracell Ultras with M3 Technology or Energizer E2 Titanium	These batteries will provide increased battery life.
GOOD	Alkaline Batteries	These batteries should provide approximately 30 kills or 90 days of standby power.
NO!	Heavy Duty, Super Heavy Duty, Extra Heavy Duty, Carbon Zinc, non- alkaline	Are not recommended for the Rat Zapper <i>Ultra</i> .
NO!	NiCad (Nickel Cadmium) or NMH Rechargeables	Are not recommended for the Rat Zapper <i>Ultra</i> ..

* Check Rat Zapper *Ultra* daily for activity. Zapped rodents that are not removed promptly deplete batteries and greatly reduce expected battery life.

What do the green and red lights on the Rat Zapper *Ultra* mean?

GREEN LIGHT:

Battery check - When you turn the **Rat Zapper *Ultra*** power switch to the *ON* position, **the** green light will blink once, then it will turn off. This tells you the battery quality is good. If the green light does not turn on at all, replace the batteries. (See chart above for Recommended Batteries.)

RED LIGHT:

Rodent Check - The **Rat Zapper *Ultra*** red kill indicator light **will blink repeatedly** when you've killed a rodent. (*NOTE: A blinking red light with no rodent inside may indicate moisture has caused a "false trip" of the unit or that the unit requires cleaning. See reverse side of this sheet or "Rodents 101" for instructions.*)

INSTRUCTIONS FOR CLEANING (Remove batteries first!)

When dust, dirt or other contaminants accumulate in the Rat Zapper *Ultra*, you will need to clean the unit, otherwise it may cause a false trip, making the red light blink repeatedly when you first turn the Rat Zapper *Ultra* on.

1. Remove batteries before cleaning to insure safety.
2. Obtain an inexpensive, thin aluminum pan large enough in width and length to accommodate the Sat Zapper *Ultra*.
3. Fill the pan with approximately 1 inch of warm/hot water, and some dish detergent. Set the Rat Zapper *Ultra* in the pan and let it soak for approximately 1 hour (to loosen debris.)
4. Using a soft bristle or bottle brush commonly found in the cookware section of your local supermarket, gently brush the bottom of your Rat Zapper *Ultra*.
5. To rinse, carefully allow a gentle stream of fresh water to flow over the cleaned bottom surface of the Rat Zapper *Ultra*. Do not spray the unit out or allow moisture to intrude into the electronics that are housed at the top of it as this may cause the electronics to short out and impair the unit's performance.
6. After cleaning and rinsing the bottom of the Rat Zapper *Ultra* thoroughly, allow the water to drain and air dry completely (do not use air compressor) before putting it back into service

RECOMMENDATIONS FOR OUTDOOR USE

TO MINIMIZE THE CHANCE OF FALSE TRIPS AND DAMAGE TO THE ELECTRONICS

- For continuous use outdoors purchase a Rat Zapper *Rat's Nest* (Our *Rat's Nest* housing is designed to protect your Rat Zapper *Ultra* from water and other elements).
- A temporary solution for the outdoor use of the Rat Zapper *Ultra* is to place it under a weather-proof-tarp, or cover it with plastic, leaving the entry open.